

# Any Single Pilots Out There?

OPSGROUP Team  
22 June, 2021



The big talking point of the moment – Airbus and Cathay Pacific's project to have **only one pilot in the cockpit during cruise**.

So let's take a look at what this might mean for **safety, operations** and **pilots** worldwide.

## The headlines are misleading

Cathay and Airbus have **not** designed a new A350 which no longer needs pilots operating it. There is **no** mega computer AI robot involved which is stealing our job.

The plan is to simply allow **one pilot to go and rest during “quiet cruise” phases**, while another pilot remains in the cockpit vigilantly monitoring (and probably with toothpicks propping their eyes open). This will allow them to potentially reduce the number of crew required on long haul flights, and while it means a change to procedures it is not really, as many are reporting, a leap towards pilotless flight decks.

## Maybe just a small step

So, what are the considerations here that people are talking about?



Cathay Pacific are in talks with Airbus on this project

## **GermanWings**

The GermanWings accident resulted in a rule that there must be two persons in the cockpit at anytime. So if a pilot needed a bathroom break, a cabin crew member was required to come in. This was fairly contentious at the time because, as many pointed out, **what is a cabin crew member going to do** if a "situation" arises?

This **rule was eventually revoked**, in part because EASA and other authorities brought in new regulations relating to pilot psychometric testing. However, with only one pilot in the flight deck, this does raise various safety concerns – from events similar to the GermanWings accident, to the question of pilot incapacitation or even, what do they do if they need the loo?

## **What about the AF447 accident?**

AF447 was, in part, **attributed to the experience levels of the two crew in the flight deck** – both First Officers while the Captain was out sleeping.

**Using cruise relief pilots is not a new thing** though, and in order to operate with a single pilot, that pilot will presumably need to meet a minimum experience level. Additionally, the Captain will maintain the decision as to when they leave the flight deck in their First Officer's hands.



Big storms on the horizon? Maybe stay in for a bit longer.

The lonesome pilot can also recall their colleague to the flight deck should a situation require it. So the question really comes down to whether a situation is likely to arise where, by **having only a single pilot the result is more critical or catastrophic** than if two had been present and therein lies the problem - because years of aviation safety studies have shown time again that there is a reason we operate with two crew.

### **Safety in numbers**

Modern aircraft, and the A350 in particular, have **many levels of safety and redundancy** to support the crew. They can automatically fly TCAS maneuvers. They can carry out an emergency descent at the push of a button. In addition, Airbus are working to demonstrate that their aircraft and systems are robust enough to basically not really fail. They are also designing them to be able to **autonomously handle any situation without pilot input for 15 minutes**.

**This will be a big deal.** It will mean, should something fail, *and* the single pilot be incapacitated, that there is time for the second pilot to wake up and make it to the flight deck to solve the situation. However, **recent aviation accidents involving malfunctioning systems** (designed to minimize pilot workload), and ongoing concerns about automation complacency highlight the potential downside of such advancements.

### **Can ETOPS can teach us something?**

The A350 was certified for 370 minutes ETOPS. That's a long time. It is over 6 hours. 6 hours on one engine potentially. So what leads to this?

ETOPS is given to the operator, not the aircraft, and it is based on the operator's ability to demonstrate necessary airworthiness, maintenance and ops requirements. **It is really a statistical thing.** If an operator hasn't had an engine issue in a really long time then they are probably going to be able to get a better ETOPS approval.

## **So what does this have to do with only one pilot in the flight deck?**

Well, it boils down to the same thing – statistics and procedures:

- How often does something go wrong in the cruise (which requires two pilots to handle it)?
- What procedures will be in place for ensuring safety and redundancy levels are maintained?

The answer to Question 1 might be “*hardly ever*”, but aviation safety improvements are built on the fairly simply idea that **if there is a risk, find a way to mitigate it.**

Even if that risk is minute, if it can be removed it should be. This is why astronauts have their appendix out before heading into space. This is why we have redundant systems onboard, or each pilot eats a different meal. Statistics might suggest an event occurring which a single pilot cannot deal with and which then results in a fatal accident or hull loss is tinier than a hair on a fleas back...

**But if a risk exists that can be mitigated simply by retaining two pilots in the cockpit, then two pilots should remain.**

### **A Disco onboard**

They gave the A380 a bar and showers, now the plan is to have Discos...

DISCO actually stands for Disruptive Cockpit (I am not sure that sounds any better). This is the Airbus project looking at enhanced cockpit design to enable single-pilot operations on new aircraft.

The DISCO concept is looking to place core technologies into the flight deck in a ‘multi modal’ way. Things like pilot monitoring systems which track eye movement, voice recognition for commands, improved ground collision avoidance systems, new navigation sensors.

### **And of course pilot health monitoring systems.**

An integral safety aspect of this concept lies in the monitoring of the sole pilot, and the availability of a system to detect if they become incapacitated, and to alert the remaining crew member.



Not an entirely new concept

### It is only happening in 2025

The plan is to implement this in 2025. That is **3 and a bit years of procedure writing, regulation making, testing and trialling** before it is put into action, and there are a fair few obstacles that stand between now and that day :

- Regulators will be looking at their procedures with a fine tooth comb
- The pilot will probably need monitoring, particularly to ensure incapacitation does not occur (or if it does, the other pilot can quick-foot it back)
- There will need to be pilot training in place
- Airbus need to hit that 15 minutes of safe autonomy.
  - And these systems will also need to deal with situations where 'Black and White' failures do not occur. When you consider the multiple, varied and often "illogical" failures which can arise from a lightning strike, a bomb onboard, or multiple computer failures this does not look as simple as Airbus might say
- The approvals for this do not just sit with the Hong Kong authorities. Any state that the airline might overfly with only one pilot in the driving seat is going to have to be convinced as well
- Passengers will need convincing...

And they still need to answer the question of the toilet. We all want a little more information on how that

'specially designed unisex toilet' to be used 'in coordination with ATC' will work.



A new flight deck concept?

### **If this happens, they won't need pilots anymore**

This is a contentious one to raise right now. Say 'single pilot' or 'autonomous systems' and a lot of pilots break out in a sweat, seeing themselves replaced by AI computers. But aviation has always been very innovative and those in it have always had to adapt to new technologies. Take a glance back to the 1980s and flight engineers were still a relatively common site in flight.

Ignoring the rather decimating impact of Covid though, **aviation was growing, and it was growing fast.**

Chances are it will again.

There are around 200,000 active pilots and forecasts suggested upwards of 500,000 would have to be trained over the next two decades to meet forecast growth demands. Even if every (long haul) flight deck sees the number of crew in it halved, it is still probably safe to say none of the current or new generation of pilots will be out of work anytime soon.

### **But we still are not convinced**

There are unresolved questions here. **The main one being "Why?"**

You see, there is already this rather marvelous thing in an airplane - it can watch the pilot, it can monitor aircraft systems, and it can take over no matter what the failure or the complexity of that failure might be...

**It is called "the other pilot".**

There is a good reason why aircraft are multi-crew machines. So why are Airbus and Cathay Pacific investing millions into developing systems which can do this?

### It isn't for safety...


This is being driven, not by manufacturers looking to increase safety, but by **an operator looking to reduce costs**. And for many, that appears an unwise and arguably unethical reason. Even if the statistical impact on safety is a 0.0001% decrease, that is still an unacceptable decrease when it is made for business reasons. There are also a great many places within an airline or operation where costs can be cut, and when cuts are made these should never occur at the price of safety, even if that price does seem negligible.

*The main photo is of a pair of VietJet co-pilots who got married - because we think that's nice, but also because we liked the play on 'single pilot' in the flight deck idea. Congrats to them both for their lovely day!*

---

## No Room for Error - GNE's and the North Atlantic

Chris Shieff  
22 June, 2021



Advances in technology mean that aircraft in the North Atlantic High Level Airspace (NAT HLA) are flying laterally, longitudinally, and vertically closer than ever before. But North Atlantic gross navigational errors (GNE's), which are lateral off-track deviations of 10nm or more, still occur regularly, and jeopardise the safety of you and the traffic around you. So don't leave it up to Air Traffic Control (ATC) to discover your GNE! In this article, let's look at some common human slip up's that lead to GNE's, and what we can do to prevent them.

[heading]Pre-Flight[/heading]Operating to the highest standards of navigational performance demands the **tedious and careful monitoring** of aircraft systems. Unfortunately, humans are by nature not the best

monitors. During the long quiet of an oceanic crossing, we can fall victim to **cognitive traps** such as change blindness, expectation bias, and complacency.

But the potential for error on Atlantic crossings begins well before the first coast-out waypoint. In fact, it begins before take off. The following four areas are where strategies in mitigating a GNE begin.

## 1) Data Entry

### Via ACARS:

Many pilots now use ACARS to automatically downlink the entire flight plan and winds aloft directly to the FMS. But an over-reliance on automation can lead to complacency, and so **the more reliable the system, the more complacent we become** as monitors. In one incident, a Boeing 747 suffered a GNE of **120nm**. The flight plan downlink from ACARS unfortunately contained one bad coordinate that went unnoticed. Once lured into complacency by such reliable technologies, there can be a temptation to omit cross-checking.

What can we learn from this? Always verify the **full** coordinates in an ACARS downlinked flight plan. Similarly, if several different flight plans were run, ensure that you request your downlink using the **most current and filed flight plan number**.

### Manually:


A manual entry means a pilot inserts the flight plan's waypoints directly into the aircraft's flight management system (FMS). But no matter how meticulously one may be, manual data entry can still produce errors. Then how do we guard ourselves against these errors?

Firstly, **avoid using ARINC 424** shorthand for programming oceanic points. This has been a factor in many GNE's, given how easy it is to misplace the letter as a prefix or suffix. For instance, consider how simply misplacing the "N" could cause a drastic lateral deviation:

- 50N60 = 50N 160W
- 5060N = 50N 060W

If you have the capability on your aircraft, use the full coordinates, including minutes.

For the last few years, use of half degrees of separation has been on the rise in an attempt to enhance airspace efficiency. But on flight displays units that only show 7 digits, these half degree coordinates are misleadingly displayed as full coordinates. For instance, the half coordinate N55°30' W020° will display as N55°W020° (see image below, which shows identical waypoint labels for points separated by half a degree!). In this case, it is imperative to view the expanded version of coordinates (degrees *and* minutes).



Another frequent error leading to GNE's is *transposing* numbers during data entry. This commonly occurs when you complete almost the entire crossing along one degree of latitude, then fly the last waypoint at a different latitude. For example, with a cleared route of 57°N 050°W, 57°N 040°W, 57°N 030°W, **56°N 020°W**, one can accidentally enter **57°N 020°W**. This will put you 60nm off course.

But there is good news! These errors are easy to recognize and avoid by having a specific method of waypoint verification.

## 2) Waypoint Verification

Whether entered via ACARS or manually, both crew members must come together to perform a **thorough cross-check**. The following method recommended by ICAO in Doc007 seems to work the best:

- One pilot reads the waypoint/coordinates, bearing and track from the FMS.
- On the master document, the other pilot will circle the waypoint to signify the insertion of the correct FULL coordinates in the navigation computers
- The circled waypoint number is ticked, to signify the relevant track and distance information matches
- (In flight) The circled waypoint number is crossed out, to signify that the aircraft has overflowed the waypoint.

[fancy\_box box\_style="default" icon\_family="none" color="Accent-Color" border\_radius="default" image\_loading="default"]

### ***Cognitive Traps:***

**Expectation Bias** is when your perception is influenced by your preconceptions. It is vital that the second crew member crosschecks **from the FMS/CDU** to the master document – and not vice versa – thereby increasing the chance of spotting an error.

**Pop-up trip hustle** – It's one thing reading about waypoint verification, but it's another thing actually sitting down and taking the time to do it. Do not be tempted to crosscheck your own work because you're in a time crunch – it requires at least **two separate sets of eyes**.[/fancy\_box]

### 3) Initialisation of navigation systems

The navigational integrity of your entire flight is predicated on an accurate starting position. Even a small error with on the ground can translate into a gross error later down the line in flight.

The FMS GPS position and your current parking coordinates (found on the 10-9 pages) must match. Avoid using "last position" function in the FMS – if you were towed overnight, the "last position" will be your previous location, not your current one! Sounds obvious, but mistakes happen.

Inertial systems, once aligned, must also complement the GPS coordinates. Initialisation of inertial navigation systems can take between 6-15 minutes, and errs on the longer side at more northerly latitudes – so be patient! Moving the aircraft during alignment **will cause an alignment error**. **Bottom line: avoid repositioning/towing the aircraft during alignment, even it is to a nearby spot on the same ramp area**. Position errors like this cannot be corrected once in flight.

### 4) Your Master Clock - (iPhones not authorised!)

Since our ETAs for oceanic waypoints must be accurate within +/- 2 minutes, it is vitally important that, prior to entry into the NAT HLA, your master clock is accurately synchronised to UTC. ICAO Doc007 has a list of approved sources from which you can set your aircraft master clock (and your iPhone isn't one of them!). You are approved to use the GPS time which can be found in the FMS.[/fancy\_box]  
box\_style="default" icon\_family="none" color="Accent-Color" border\_radius="default" image\_loading="default"]

#### ***Cognitive Trap:***

Close to the E/W Greenwich line or close to the equator, you'll just be on the fringes of the opposing segment. So, take a close look at the E/W or N/S letter coordinates, especially if you are usually accustomed to flying from one particular geographic area.[/fancy\_box][heading]Clearances & Communication[/heading]With a move away from spoken communications and towards datalink procedures, requesting, copying and verifying a clearance becomes a much simpler task! But it is still important to know your own limitations in the rare instance that you need to copy a clearance via voice.

#### **Casual radiotelephony should be avoided**

Casual radiotelephony can be the source of misunderstanding coordinates or clearances, and so all waypoint coordinates must be read back in detail, adhering strictly to standard ICAO phraseology. An example of standard ICAO phraseology requires enunciation of every individual digit. 52 North, 030 West would be read back as "Fife two north, zero tree zero west" as opposed to "fifty-two north thirty west". Have no doubt about it, Shanwick can be the most strict in this regard.

#### **Distractions and workload**

If your departure airport is close to the oceanic boundary, e.g. Shannon or Miami, the benefit is that you will copy your oceanic clearance on the ground. Unencumbered by distractions typically associated with being in flight, you can focus almost fully on the task at hand. However, most flights pick up an airborne

clearance, and it is important to **prioritise this for a period of low workload**.

Take the example of a Bombardier Global Express crew that narrowly avoided a GNE after copying a clearance. While they were in the midst of crosschecking the clearance with the FMS and climbing to their initial altitude, the flight attendant approached them with an issue. Instead of waiting, one of the pilots attended to the problem. A new waypoint wasn't entered, and it was later caught by ATC in a position report. **Try to avoid non-vital tasks until ALL the steps regarding copying, verifying and inputting a clearance are complete.**

Following these simple standard operating procedures (SOPs) step-by-step will guard against clearance errors. If the steps are interrupted for any reason, start again from the beginning.

- Two pilots monitor and record the clearance. The Pilot Monitoring (PM) will contact clearance delivery, while Pilot Flying (PF) monitors both the primary ATC frequency and the clearance delivery frequency.
- The PM then records the clearance on the master document. The PF also copies down the clearance separately.
- Clearance is read back to ATC. *Any disparities between both pilots' interpretations of the clearance must be clarified with ATC.*
- A deliberate cross check of the clearance to the filed flight plan and the FMS is made.

## Re-Clearance

According to ICAO Doc007, "*In the event that a re-clearance is received when only one flight crew member is on the flight deck...changes should not be executed...until the second flight crew member has returned to the Flight Deck and a proper cross-checking and verification process can be undertaken.*" Sorry, they just don't trust you to do this by yourself, and neither should you!

Errors associated with re-clearances, re-routings and/or new waypoints continue to be the most frequent cause of GNE's. Therefore, a re-clearance or amended clearance should be treated virtually as **the start of a new flight** and the procedures employed should all be identical to those procedures employed at the beginning of a flight.

- Both crews note the re-clearance
- Reply to ATC via ACARS or voice
- Amend the Master Document
- Load the new waypoints into the FMS from the updated Master Document
- One pilot verifies the input of the new waypoints reading **from** the FMS
- Verify the new tracks and distances, if possible
- Prepare a new plotting chart/re-plot in Jeppesen EFB

With datalink, you might have the capability to load the new route directly from the ATC message into your FMS flight plan. This will eliminate a transcription error on your part, but you cannot always count on the FMS to load this seamlessly. Oftentimes, if a revised coast-in waypoint doesn't connect with your originally planned domestic airspace airway, it might cause a discontinuity. Worse, some crew have experienced their entire domestic flight plan drop out, left with only the oceanic portion.

## Conditional Clearances - There's always a catch!

A conditional clearance is an ATC clearance given to an aircraft with certain conditions or restrictions, such as changing a flight level based on a time or place. Conditional clearances add to the operational efficiency of the airspace, but are commonly misinterpreted by flight crews.

Shannon has been known upon first VHF contact to provide lateral conditional clearances on coast-in. For example: "N135AC, after DINIM, direct ELSOX". Often, crew have been known to read back the *correct* transmission, but then execute the wrong procedure by proceeding directly to ELSOX.

Why is this happening? In studies of linguistics, **verbs** (such as 'direct') have been noted as having a perceptual priming effect, that more **easily grabs our attention** at the expense of weaker prepositions (such as 'from' or 'after'). Listen carefully for prepositions. Similarly, in aviation vernacular, the word 'direct' means to proceed **now** to the specified waypoint. As pilots, we can distinguish this meaning with very little effort, and most of the time can expect to proceed present position direct. Thus, we are *primed* to go direct.

While this isn't a complex sentence, research indicates that transmissions involving serial recalls (such as "proceed here *then* here...") are susceptible to distortion, with the last word or item more commonly interfering with recall of the previous item.

A really simple way to prevent this is to **write down** clearances as they are being read to you, *then* read-back the transmission. You can also call attention to a conditional clearance by prefixing their read-back with the word "Verify" or "Confirm" over the radio. Via datalink, sufficient care always must be taken when factoring in all the contents of a clearance before acknowledging the message. The initial phrase "MAINTAIN FLIGHT LEVEL 300" is included to stress that the clearance is **conditional**. If the message is about to time out, and you need more time to process its contents, reply using "Standby". Respond at your own pace![fancy\_box box\_style="default" icon\_family="none" color="Accent-Color" border\_radius="default" image\_loading="default"]

### **Cognitive Trap:**

On the longer route segments between New York and Santa Maria, "when able higher" (WAH) reports might be solicited. ATC acknowledgement of a WAH report must not be misconstrued as a conditional clearance to climb. Any climb clearances will be issued **separately** from a WAH acknowledgement.[/fancy\_box][heading]Miscellaneous[/heading]

## **10-minute Check - put the (Bad) Elf on the shelf for this**

One of the best ways to capture a potential GNE and refresh your situational awareness is with the sublimely simple 10-minute check. Ten minutes after waypoint passage, you'll use your current coordinates to plot your position on your plotting chart. If the coordinates don't land on the plotted track line, an investigation into the source of the error must begin immediately. It doesn't hurt to even make additional plots between waypoints too, but ICAO only requires the one 10-minute check.

Today, more pilots are carrying independent GPS units in their flight bags, providing crew with own-ship on their oceanic route map. Tempting though it may be to use this for present position information, it is currently not an approved source of navigation, and should **NOT** be used in lieu of a 10-minute check.[fancy\_box box\_style="default" icon\_family="none" color="Accent-Color" border\_radius="default" image\_loading="default"]

### **Cognitive Trap**

It is easy to forget about the 10-minute check. Setting a timer once your waypoint passage tasks have

been completed will help remind you to do so.[/fancy\_box]

## Autopilot mode - “Wait, are we supposed to be in heading?”

Incorrect autopilot mode selection has been known to be a factor in GNE's. On an oceanic crossing, you can bank on being in NAV or LNAV most of the way across the Atlantic. But perhaps you used heading mode to deviate for weather or to intercept a SLOP. It is not uncommon among pilots to spare your passengers two steep banking turns (thanks LNAV!) by manually flying a SLOP intercept in heading mode. But if you forget to re-engage LNAV, you will continue drifting on your merry way, further and further off course.

Distraction, fatigue or complacency are common reasons for losing mode awareness, so the following simple tricks will help mitigate autopilot induced GNE's.

- It helps to **verbally announce** when you are transitioning temporarily into heading mode, to bring both pilots in the loop.
- Employing **sterile cockpit** until you're back in LNAV will help mitigate distractions.
- In an abundance of caution, you can keep a **finger** on the heading button or heading dial until you are back in LNAV will serve as a reminder.

[fancy\_box box\_style="default" icon\_family="none" color="Accent-Color" border\_radius="default" image\_loading="default"]

## Cognitive Trap:

The flight mode annunciators (FMA's) are the most reliable indicators of automation selection – more so than the flight guidance panel! Yet, a study found that pilots pay superficial attention to the FMA's during critical mode changes. Don't waste a valuable resource, and do consciously **bring the FMA's into your scan**.[/fancy\_box] Deliberate cross-checking and monitoring are a critical last line of defense for which we, as pilots, don't get explicit training, but are nevertheless expected to perform effortlessly. But over the North Atlantic, there is little room for error. So, let's recap what can be done!

1. **Allow sufficient time on the ground to set up**
2. **Closely scrutinise data entry - whether the source is human or ACARS!**
3. **Work together on waypoint verification**
4. **Don't work single pilot - always keep all crew in the loop**
5. **Deal with clearances and re-clearances methodically**

Understanding our vulnerabilities is key to the process of mitigating errors. Armed with an understanding of our own limitations, and an appreciation for the practices and habits mentioned above, a 'would-be' GNE can be averted.

## Links

ICAO Doc 007

Global Operational Datalink Document (GOLD)